

INSTALLATION

Perform the installation in the numerical order.

1. Fix mounting brackets (4 places) to low velocity unit.
2. Remove plastic cover strips (E) from unit.
3. Locate unit against wall and secure through mounting brackets.
4. Fix duct cover support brackets (A) to wall between unit and ceiling.
5. Position AS base against lower flange of the unit.
6. After installation of ductwork, locate DC duct cover as follows :
Locate DC duct cover section (F) on top flange (G)
7. Secure DC duct cover with screws through cover into support brackets fixed to wall (B).
8. Re-fit plastic cover strips between DC duct cover and AF unit, and between AS base and AF unit by bending strip back on itself (E) and pressing bead into groove in flange (G).
9. When multiple sections of DC duct cover are used (D) an aluminium coupling flange (C) is needed.

