Halton Jaz JDS – Variable air volume diffuser (VAV)



Overview


- Stable throw length with variable air flow rates for enabling draught free air distribution
- Installation for suspended ceiling
- Designed for systems with constant static pressure ductwork system
- Integrated balancing plenum with measurement and adjustment functions
- Effective sound attenuation

Applications


• Available for Halton Workplace applications




Quick selection



Dimensions








NS	Ø D	H1	H2
125	124	276	114
160	159	276	114
200	199	326	139
250	249	326	139

Material

Part	Material	Finishing	Note
Diffuser plate	Steel	Powder painted, white (RAL 9003)	Special colours available
Front panel	Steel	Powder painted, white (RAL 9003)	Special colours available
Control cone	Steel	Powder painted, black	_
Gasket	Rubber compound	_	_
Plenum casing	Galvanised steel	_	_
Control box	Galvanised steel	-	_
Attenuation material	Polyester fiber	_	_
Spigot with gasket	Galvanised steel	_	Gasket of rubber compound
Measurement and adjustment module (MSM)	Body: aluminium Plate: galvanised steel Brackets: galvanised steel Plastic parts: polypropylene (PP) Spindle: stainless steel	_	_




Function



The Halton Jaz Conical VAV is an active ceiling diffuser for supply air in variable conditions.

Air is supplied horizontally to the room space mainly through the slots of the diffuser.





The room air will circulate through the perforation in the front panel to the sensors located inside the diffuser.

The unit maintains a nearly constant outlet air velocity between the minimum and maximum airflow rates, create comfortable conditions and low residual air velocities in the occupied zone. Room conditions can be guaranteed without a risk of draughts, at both the maximum and minimum airflow rate.

Recommended maximum air temperature difference between supply and room air is 12 ° C.

An external room controller varies the room airflow rate by running the Halton Jaz Conical VAV diffuser actuator with a standard 0...10 VDC control signal.

The pressure dependent function of the Halton Jaz Conical VAV operates in combination with a constant pressure duct zone.

Exhaust diffuser do not include any airflow control function, will need a separate flow control damper (like Halton HFB).

System package

Halton Workplace WRA room automation system package for Halton Jaz Conical VAV (JDS) diffuser

Halton Workplace WRA is part of the Halton Workplace solution offering.





Fig.1. Halton Workplace WRA room automation controller integrated to Halton Jaz Conical VAV diffuser

Halton Workplace WRA is a controller especially designed for controlling the automation system of office spaces and meeting rooms. It is used for controlling the ventilation airflow, room temperature, and indoor air quality.

The Halton Workplace WRA room automation package consists of a controller unit and optional components depending on customer needs: a wall panel and sensors for temperature, CO₂, occupancy, pressure, and condensation.

There are options available for the controller unit and wall panel, depending on the number of controls and sensors required. The Halton Workplace WRA room automation controller is always combined with other Halton products for adaptable and high-level indoor climate.

Application area

- Controlling the ventilation airflow, room temperature, and indoor air quality in office spaces and meeting rooms
- The Halton Workplace WRA room automation controller is an important part of the Halton Workplace system, controlling room units and airflow control dampers
- Overall Halton Workplace system includes:
 - Room air conditioning applications with Halton Workplace WRA room automation controller:
 - Active chilled beams
 - Exhaust units
 - VAV dampers
 - Active VAV diffusers



- Halton Max MDC zone control damper
- Halton Workplace WSO system optimiser

Key features

- Factory-tested controller and wiring, easy to install
- Pre-installed project-specific parameters, quick to commission
- Several operating modes based on occupancy, thermal comfort, and indoor air quality
- Enables fully flexible layout solutions for changing needs in office environments
- Highly energy-efficient and reliable system operation

Operating principle

The Halton Workplace WRA room automation controller operates with Variable Air Volume (VAV) dampers and active chilled beams of the Halton Workplace system. These are used for adjusting the ventilation airflow, room temperature, and indoor air quality in office spaces.

Each room unit in an office space can have its own dedicated Halton Workplace WRA room automation controller, or a single controller can control multiple room units. The Halton Workplace WRA room automation controller can automatically adjust the system according to the indoor environment level preferred by users. Each room unit having its own dedicated controller brings maximum flexibility.



Room automation: Halton Jaz Conical VAV (JDS) active diffusers controlled with Halton Workplace WRA room automation controllers




Fig.15. Two Halton Jaz Conical VAV (JDS) active diffusers controlled with Halton Workplace WRA room automation controllers in a single office room

Room automation description

In this configuration, two Halton Workplace WRA room automation controllers (type DXR2.E12P-102A) control two Halton Jaz Conical VAV active diffusers. Each active diffuser has integrated temperature, CO₂, and occupancy sensors. The pressure sensor is integrated into the Halton Workplace WRA room automation controller. The system also includes an exhaust VAV damper, and radiator heating water valve control. One Halton Workplace WRA room automation controller can individually control up to four terminal units, and there can be several Halton Workplace WRA room automation controllers in the room.

Design criteria for room automation

- Active diffuser has integrated balancing plenum with measurement and adjustment functions
- Active diffuser has integrated CO₂, occupancy, and temperature sensors
- Pressure sensor integrated into Halton Workplace WRA room automation controller



- Radiator heating water valve control
- Exhaust airflow control

Schematic drawing




Fig.16. Schematic drawing: Halton Jaz Conical VAV active diffuser controlled with Halton Workplace WRA room automation controller

Equipment list

Code	Equipment
RC	Controller unit
FG	Airflow damper actuator
FC	Airflow measurement
Н	Water valve actuator
OS	Occupancy sensor
PE	Pressure sensor
CO2	CO ₂ sensor
TE	Temperature sensor



Wiring diagram


For the wiring diagram of similar configuration, see the product pages of the Halton Workplace WRA room automation controller.

Components and order code examples for the system

- 2 x Active diffuser: Halton Jaz Conical VAV
 JDS/S-125 CO=SW, IO=NA, RC=NA, SE=SA2, ED=N, CP=NA, ZT=N
- 1 x Exhaust unit: Halton AGC Exhaust grille + Halton PRL Plenum for grilles
 AGC/N-400-100 FS=CL, ME=A, FI=PN, CO=W, ZT=N+PRL/F-400-100-160
- 1 x VAV damper: Halton Max Ultra Circular or Halton Max One Circular – MUC/G-160, MA=CS
- Automation package: 2 x Halton Workplace WRA room automation controller unit with related components
 - WRA/JDS-E21-JD-EX4, WP=NA, LC=NA, SE=NA, SW=NA, ST=IA, SL=OI, PM=P2, TC=NA, CV=NA, RV=RA, ZT=N

Note: For more information, see the product pages of the Halton Workplace WRA room automation controller.

Installation





The Halton Jaz Conical VAV active diffuser shall have a minimum safety distance of 3 x duct dimension to ensure reliable measurement and accurate control of the airflow rate.

Hang the diffuser by using the brackets located on two sides of the plenum.





Alternatively ceiling integrations











Clip-in ceilings

Fineline-15 ceilings



NS	ØD	H1	H2
125	124	276	114
160	159	276	114
200	199	326	139
250	249	326	139


Controls

The Halton Workplace WRA controller is a room controller dedicated to complete room applications providing the demand-controlled ventilation.

- Halton Jaz Conical VAV diffuser integrated with room controller
- Room air temperature measurement to control space temperature
- Occupancy sensor for demand based operation located outside of the diffuser (separate ceiling installation)
- Air quality control with carbon dioxide sensor (CO₂₎


The Halton Workplace WRA room controller provides a wide variety of connections for sensors and actuators and the possibility to connect a wall mounted panel with or without a display for local set points adjustment e.g. temperature, and a wireless remote control.

Wiring



Control that the actuator settings are in line with the factory pre-setted DIL switches.





Control signals in junction box:

Terminal 1 Power supply 24 VAV


Terminal 2 Ground

Terminal 3 0 VDC = minimum position airflow

10 VDC = maximum position/airflow

Terminal 4 Not connected (feedback form actuator)

Commissioning



Make sure that the control plate of diffuser is fully open (at the lowest position). This can be done either mechanically or electrically:

- If the power is not connected to active diffuser, detach the control plate for releasing the actuator clutch and pull the control plate to the fully open position.
- If a 24 VAC power supply is connected to diffusers, please make sure that the control signal is constantly at 10 VDC.

Check that the duct zone constant pressure is at the intended level (for example, between 30 and 50 Pa).

If the duct zone pressure is too low and the zone pressure control damper is fully open, you should either adjust the supply fan pressure set point to be higher or adjust the MSM adjustment unit.

The zone pressure control damper shall have a sufficient operative differential pressure over the damper (for example, 30 Pa or more).



Adjustment

The maximum airflow rate of the active diffuser is measured and adjusted using the MSM module.

Airflow rate is calculated using the pressure difference reading and the k factor.

$$q_v = k * \sqrt{\Delta p_m}$$

qv Calculated airflow rate (I/s)

k Factor from the tableΔp_m Measured pressure (Pa)

The k-factors for installation with different safety distances

(D = duct diameter).


NS	> 8 * D	min 3 * D
125	9,5	12,6
160	18,0	22,2
200	28,6	32,9
250	44,6	46,0

If the airflow rate of the active diffuser is too high, adjust the position of the MSM adjustment unit to closer position. If maximum airflow can't be reached, open MSM module first full open and if this is not enough, increase the duct zone pressure

The minimum airflow for the diffuser is fixed by factory and cannot be adjusted.




Servicing



For servicing open the front panel of the diffuser and detach the flow control element.

Detach the flow control plate by opening the screw (1) and remove the plate (2). Remove the motor assembly (3) on JDS body by pushing the mounting shaft and let it hang on the wire.





The MSM is removed through diffuser outlet by pulling from it's body – not from the measurement tubes or control spindle.

Clean the parts with a damp cloth, instead of immersing in water.



Replace all parts in opposite order. Ensure that the actuator is locked and the control plate is in right position.

Specification

The Halton Jaz Conical VAV supply air diffuser is made of painted steel with a white (RAL 9003) standard colour.

Air is introduced into the space through the adjustable control plate and the side slots of front panel, ensuring a high mixing rate. The diffuser maintains appropriate discharge velocity throughout the total airflow range.

The diffuser is integrated to a balancing plenum designed for the active diffuser installation and equipped with a measurement and adjustment module.

The diffuser has a gasket of rubber compound to ensure tight connection to the duct work.

The diffuser enables to be equipped with sensors and control system.

Order code

JDS/S-D; SP-CO-IO-ZT

S = Model

S Supply

E Exhaust

D = Duct connection (mm)

125, 160, 200, 250

Other options and accessories

SP = System package

N No

Y Yes

CO = Colour

SW Signal white (RAL 9003)

X Special colour

IO = Ceiling type

NA Standard T-profile

DC Clip-In ceiling

FL Fineline-15

ZT = Tailored product



N No Y Yes (ETO)

Code example

JDS/S-200, SP=N, CO=SW, IO=NA, ZT=N

